


3 IN 1 MULTI-CART

Multi-Cart work modes:



MODE 1:
Hand Truck

ATTENTION:

- Read instructions thoroughly before proceeding
- Tighten all parts by hand, DO NOT use power tool
- For your safety, DO NOT overload the heavy duty trolley & DO NOT exceed load capacity rating



MODE 2:

45° Trolley. To position:

Step 1: Raise rear handle assembly locking lever & extend and tilt trolley as shown in diagram 2.

Step 2: Pull locking pin at the top of the main body and locking to the rear handle assembly.

Step 3: Raise Base extension



MODE 3:

FLAT BED TROLLEY:

Step 1: Pull the locking pin at the top of the main handle

Step 2: Slightly tilt the rear handle back & lower the main handle to the mounts on the rear handle.

Converts to:


- 2 Wheel Trolley
- 4 Wheel Flat Bed Trolley
- 4 Wheel 45° Trolley

K12119
ED1 MAR 2015




PTO for assembly instructions


Assembly Instructions:




① Layout base plate




② Slide the small aluminium pieces on to the base plate with the wide side facing inwards.




③ Slide the main frame over the outside of the two small aluminium pieces.




④ Find the left and right axle bracket and locate them at the base.




⑤ Align all the holes then Insert the 4 bolts through the axle brackets, main upright, small ally piece into the base plate.



⑥ Insert the extension bar and line up holes on the brackets with the 4 bolt. Attach nylon nuts, then tighten. Do not overtighten.




⑦ Slide Axle through the top axle locating holes. Line up holes in the axle with the slots on the bracket and insert roll pins.




⑧ Slide spacers on to the outside of the axle push hard up against axle bracket. Slide wheels on to axle.



⑨ Slide one washer on each side then insert the split pin through the hole in the end of the axle. Once fully inserted, bend the ends out.



⑩ Bolt the rear handle to the locating bracket with the M12 x 110 bolt and nylon nut.



⑪ Feed the locking lever through its mounting point. Then feed the spring onto the bottom of the locking lever & tighten the spring retaining clamp with a screwdriver.