



# Instructions

K8003

MAGNETIC TELESCOPIC PICK-UP  
TOOL WITH LIGHT

**KINCROME**

# Instructions

Tool Required

PH#0 screwdriver.

1. On the Pick up tool, rotate to locate the screw



# Instructions

2. Remove the screw, using Phillips #0 screwdriver
3. To remove the LED / Magnetic Tip, rotate anticlockwise.  
Be careful not to loose the batteries
4. Remove the battery protector (Red disc)



# Instructions

5. Replace the LED / Magnetic tip, turn in a clockwise direction.
6. Replace the screw and tighten
7. Extend the telescopic pick up tool and the LED will illuminate.
8. Once the extension is retracted, the light will turn off.

