

KINCROME

Neck Light 300 lumens

K10334

Specifications



WARNING:

This operating manual contains important safety information, read carefully & understand all information before operating the Neck Light. Save this manual for future use.

LED type	3W SMD LED, 6000K
Light output	Low - 150lm, High - 300lm
Runtime	Low - 5hrs, High - 2hrs
Battery	2 x Rechargeable 3.7Vdc 350mAh Li-Ion
Charge time	2.5 Hours
IP rating	IP54 - Dust & water resistant
Weight	140 grams
Measurements	L130 x W45 x H230mm



Safety Warnings

Advice & Important Information!

- Ensure the Neck Light is fully charged before initial use.
- DO NOT turn the Neck Light on while it's being charged.
- DO NOT leave battery in a discharged state, recharge battery immediately. Before storage, fully recharge the battery, subsequently recharge the battery at least once every six months of non-use.
- DO NOT dispose of this Neck Light in normal household waste, the battery must be recycled or disposed of properly in accordance to local laws and regulations.
- DO NOT open, crush, heat above 60°C (140°F) (for Li-Ion) or incinerate.
- Battery life is affected by different lighting modes.
- DO NOT look directly at the LED. This may cause temporary blindness, or permanent damage to the eyes.
- DO NOT shine the light directly into human eyes. This may cause temporary blindness, or permanent damage to the eyes.
- DO NOT operate in direct sunlight or extreme temperature conditions (below -10°C or above 40°C).
- The LED will become hot when switched on; DO NOT touch and DO NOT place face down on any surface – risk of fire!
- DO NOT use the device if there is any visible damage to the housing, switch or lens.
- Keep away from children! Children should be supervised in order to ensure that they DO NOT play with the device!
- To reduce the risk of injury, close supervision is necessary when an appliance is used near children.
- Store idle light out of reach of children. Warm lights can become hazardous in the hands of children.
- DO NOT open, disassemble or attempt to modify the product; this will void the warranty and can be dangerous. Improper use or modification is not covered under the warranty.
- Take care not to let the lenses come into contact with hard/sharp objects, damage/scratches to the lenses will affect light output.
- Protect batteries from heat, intense sunlight, fire, water and moisture – danger of explosion!
- If batteries are damaged, fluids can leak out. AVOID contact as this can lead to skin irritation and/or burns. If skin contact happens, rinse thoroughly with water. If irritation persists, seek medical advice.
- Seek immediate medical assistance if battery acid comes into contact with the eyes.

KINCROME

Neck Light 300 lumens

K10334

Operation

Charging the Battery

- While holding the right LED head, peel open the USB charging port cover.
Note: Always close the USB charging power cover when light is not charging to maintain dust protection.
- Plug the supplied USB cable into the USB Charging port.
Note:
 - The USB Charging indicator will flash GREEN when the product is charging, and illuminate GREEN when the product is fully charged.
 - When the battery charge is getting low, the LED will flash 3 times. This will indicate that the Neck Light requires to be recharged.
- Once the charging cycle has completed (approx. 2.5 hours charging time), unplug the USB Cable.



Turning the Neck Light ON/OFF

The Neck Light has 2 different light settings Low mode and High mode. The On/Off button requires to be pressed in the following sequence to activate each mode, 1st press: Low - 2nd press: High - 3rd press: Off.

Description of Symbols

lm	Lumens	V	Volts	IP	Ingress protection from water, dust and debris
A	Amps (current)	mAh	Milli-Amp Hours		Regulatory Compliance Mark
	Class III protection		Do not look directly at light source		Conformity with European health, safety & environmental protection standard
	Direct current, DC				

Warranty



Kincrome Australia Pty Ltd of 3 Lakeview Drive, Caribbean Park, Scoresby, Victoria (Tel 1300 657 528) provides the Kincrome 12-Month Warranty (Kincrome Express Warranties) in respect of some of its products. If a product is covered by a Kincrome Express Warranty and it has materials or workmanship defects (other than defects caused by abnormal or non warranted use) which are covered under the terms of the relevant Kincrome Express Warranty, you can, at your cost, send the product to the above address for repair or replacement. Your rights under a Kincrome Express Warranty are in addition to any other rights you have under the

Australian Consumer Law or other applicable laws. Our goods and services come with guarantees that cannot be excluded under the Australian Consumer Law. For major failures with the service, you are entitled: -to cancel your service contract with us; and -to a refund for the unused portion, or to compensation for its reduced value. You are also entitled to choose a refund or replacement for major failures with goods. If a failure with the goods or a service does not amount to a major failure, you are entitled to have the failure rectified in a reasonable time. If this is not done you are entitled to a refund for the goods and to cancel the contract for the service and obtain a refund of any unused portion. You are also entitled to be compensated for any other reasonably foreseeable loss or damage from a failure in the goods or service'. For further details and terms please check our product guide, visit www.kincrome.com.au or call us. Every effort is made to ensure advertised stock is available, but due to factors beyond the control of Kincrome Australia Pty, Ltd, not all products advertised in this catalogue may be available at all stores. Kincrome Australia Pty, Ltd. reserves the right to correct printing errors. All sizes shown are approximate only. Accessories shown do not come with the product unless otherwise specified. Due to printing process, colours in this catalogue may vary slightly to actual item. E. & O. E. © Copyright 2022. Reproduction in whole or in part is prohibited without written approval.



Office Contact Details

1300 657 528

enquiries@kincrome.com.au

1300 556 005

www.kincrome.com.au