

# Wall Cabinet

2 Drawer  
750mm

51065

## Operation Manual



### IMPORTANT:

This operating manual contains important safety information, read carefully & understand all information before operating the wall cabinet. Save this manual for future use.



Do not open more than one drawer at a time.



Do not step on drawers.



Do not let children near the Toolbox.



Do not separate Chest from Trolley.



Do not exceed Drawer Load Limit



Not suitable for mounting in Vehicles



Lock drawers and lid before moving the Toolbox.



## Parts List



### Measurements Overall: Weight: 24.2kg

WIDTH	750 mm	DEPTH	255 mm	HEIGHT	890 mm
-------	--------	-------	--------	--------	--------

### Measurements - Inner Cavity

WIDTH	750 mm	DEPTH	192 mm	HEIGHT	760 mm
-------	--------	-------	--------	--------	--------

### Drawers

WIDTH	625 mm	DEPTH	166 mm	HEIGHT	55 mm
-------	--------	-------	--------	--------	-------

## Included



Keys x 2

Tools & Assistance  
Required for Cabinet:



2 People

# Wall Cabinet


2 Drawer  
750mm

51065

## Assembly Instructions

### Installation - Brick & Concrete

1. Drill or core a hole to the recommended diameter and depth using the fixture as a template. Clean the hole thoroughly with a hole cleaning brush. Remove the debris with a hand pump, compressed air, or vacuum.
2. Insert the Concrete/Masonry Anchors (Dynabolt) through the fixture and drive with a hammer until the washer contacts the fixture.
3. Tighten the Concrete/Masonry Anchors (Dynabolt), allowing the sleeve to twist and pull down the fixture firmly onto the substrate. For optimum performance, a torque wrench should be used.



### Installation - Wood

1. All coach screws require a pilot hole, using a general purpose drill bit such as a Twist Drill Bit, before they are screwed into place, preventing the wood from splitting.
2. Drill the hole to the required diameter and depth to the coach screw.
3. Once the pilot hole has been drilled, the coach screw can be driven directly into the wood. When using coach screws on timber it is advisable to use a washer to avoid embedding the screw head into the wood on impact.
4. Place the fixture in position on the timber/wall in place first.
5. Drive the screw into the timber/wall until secure and tight.



Coach Screw



Dynabolt

### Important information

When tightening or loosening a coach screw it is important to use the correct size spanner, wrench or impacts socket to avoid damaging the head of the screw. The size you require can be determined by measuring across the flat edges of the head and not point to point.

## Maintenance

- Periodically tighten all hardware
- Lubricate the slides twice a year
- Lubricate the lock with graphite annually
- Use a damp Microfibre cloth to clean all surfaces